

The Anatomy Of A Failed Hygienic Seal

SOLUTION: RUBBER FAB

The Perfect Surface
Hygienic Seal System

Over compression
caused *extrusion*
and *tearing* beyond
O.D. of sanitary
ferrule

Soiled area
jeopardizing product
integrity

I.D. and O.D. permanently
deformed leaving hygienic
seal unusable

Crack from over
compression

Sealing surface, because of
over compression, extruded
into sanitary tube I.D.
obstructing flow

Tear from over
compression

Positioning Ring

Sealing Surface

